

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0202-002126	R5018,R5020	DIODE-SCHOTTKY
0404-001250	D5000,D5002	DIODE-SCHOTTKY
0404-001646	D6000	DIODE-TVS
0406-001808	D6001	DIODE-TVS
0406-001809	ZD6000,ZD6001	DIODE-TVS
0406-001829	ZD1000	FET-SILICON
0505-003618	Q5000	LED
0601-003881	LED5000	IC
1001-001755	U7011,U7012	IC
1001-001977	U2000	IC
1001-002078	U2003	IC
1001-002101	U1002	IC
1201-003869	U3003	IC
1201-003915	PAM1000	IC
1201-004219	U1001	IC
1201-004271	U6002	IC
1201-004273	PAM1001	IC
1203-008859	U7009	IC
1203-008864	U7010	IC
1203-008865	U7001,U7006,U7008	IC
1203-008867	U5004,U7002,U7007	IC
1203-008998	U5006	IC
1203-009157	U7004	IC
1203-009161	U2007,U3005	IC
1203-009252	U6000	IC
1203-009320	U6001	IC
1203-009419	U7000	IC
1203-009470	U5002	IC
1203-009480	U5001	IC
1203-009483	U5000	IC
1203-009484	U5003	IC
1203-009492	U5005	IC
1205-006274	U3001	IC
1205-006337	U2002	IC
1209-002555	U2009	IC
1209-002645	U3006	THERMISTOR
1404-001724	TH2000,TH4000,TH4001	R-CHIP
2007-000140	R3003,R5028,R5029,UB	R-CHIP

5. MAIN Electrical Parts List

2007-000141	R4019,R4021,R5008	R-CHIP
2007-000141	R5016,R6001	R-CHIP
2007-000165	R5014	R-CHIP
2007-000171	R6003,R6004	R-CHIP
2007-001329	R5017	R-CHIP
2007-007134	R5027	R-CHIP
2007-007156	R5026	R-CHIP
2007-007308	R5004	R-CHIP
2007-007517	R5032,R5033	R-CHIP
2007-007573	R5024	R-CHIP
2007-007741	R5005,R5006,R6019	R-CHIP
2007-007766	R2001,R7017	R-CHIP
2007-008052	R6010	R-CHIP
2007-008055	R6011	R-CHIP
2007-008312	R2000,R4002,R5000	R-CHIP
2007-008312	R7013	R-CHIP
2007-008478	R5022	R-CHIP
2007-008483	R5046	R-CHIP
2007-008486	R5011,R5012,R5013	R-CHIP
2007-008486	R5021,R5023,R6005	R-CHIP
2007-008516	R4009,R4010,R5010	R-CHIP
2007-008516	R5035	R-CHIP
2007-008531	R5038,R7000,R7001	R-CHIP
2007-008531	R7002,R7005,R7009	R-CHIP
2007-008531	R7014,R7015	R-CHIP
2007-008542	R5025	R-CHIP
2007-008587	R1006	R-CHIP
2007-008647	R1002,R4001	R-CHIP
2007-008648	R6006	R-CHIP
2007-009111	R5039	R-CHIP
2007-009157	R5019	R-CHIP
2007-009212	R6018	R-CHIP
2007-009315	R6017	R-CHIP
2007-009354	R7016	R-CHIP
2007-009361	R1001,R5034,R6000	R-CHIP
2007-009361	R6007,R6027,R6028	R-CHIP
2007-009361	R6029	R-CHIP
2007-009410	R6008,R6009	R-CHIP
2007-009801	R5044	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009805	R1007	R-CHIP
2007-009969	R6022	R-CHIP
2007-010031	R5001	R-CHIP
2007-010202	L5011,R5002	R-CHIP
2007-010849	R4000	R-CHIP
2007-011532	R6023	R-CHIP
2007-011648	R1000	R-CHIP
2007-012197	R5003	R-CHIP
2007-012202	R5042,R5043	C-CERAMIC,CHIP
2203-000233	C6007	C-CERAMIC,CHIP
2203-000585	C5069,C5070	C-CERAMIC,CHIP
2203-000812	C6001,C6006,C6024	C-CERAMIC,CHIP
2203-000812	C6029	C-CERAMIC,CHIP
2203-001033	C7048	C-CERAMIC,CHIP
2203-005344	C5063	C-CERAMIC,CHIP
2203-005682	C1026,C1070,C1092	C-CERAMIC,CHIP
2203-005682	C5028,C5077,C5104	C-CERAMIC,CHIP
2203-005682	C5119,C6002,C6012	C-CERAMIC,CHIP
2203-005682	C6016,C7008	C-CERAMIC,CHIP
2203-005683	C6025,C6026	C-CERAMIC,CHIP
2203-005725	C7000,C7013	C-CERAMIC,CHIP
2203-005727	C2075	C-CERAMIC,CHIP
2203-005729	C6031,C6034,C6040	C-CERAMIC,CHIP
2203-005729	C6046	C-CERAMIC,CHIP
2203-005731	C6018,C6019	C-CERAMIC,CHIP
2203-005732	C5042,C6030,C6041	C-CERAMIC,CHIP
2203-005732	C6045	C-CERAMIC,CHIP
2203-005734	C1017	C-CERAMIC,CHIP
2203-005736	C1000,C1007,C1010	C-CERAMIC,CHIP
2203-005736	C1024,C1037,C1038	C-CERAMIC,CHIP
2203-005736	C2019,C2020,C2021	C-CERAMIC,CHIP
2203-005736	C2022,C2023,C2024	C-CERAMIC,CHIP
2203-005736	C2025,C2026,C2027	C-CERAMIC,CHIP
2203-005736	C2028,C2029,C2030	C-CERAMIC,CHIP
2203-005736	C2031,C2033,C2040	C-CERAMIC,CHIP
2203-005736	C2045,C2052,C2055	C-CERAMIC,CHIP
2203-005736	C2056,C2061,C2066	C-CERAMIC,CHIP
2203-005736	C3015,C3016,C3030	C-CERAMIC,CHIP
2203-005736	C3037,C3038,C3040	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C6011,C6017,L2015	C-CERAMIC,CHIP
2203-005736	L2027	C-CERAMIC,CHIP
2203-005777	C1078	C-CERAMIC,CHIP
2203-005789	C1011,C1051,C1069	C-CERAMIC,CHIP
2203-005789	C1083,C1087,C1089	C-CERAMIC,CHIP
2203-005789	L3006	C-CERAMIC,CHIP
2203-005792	C1028,C1043,C2036	C-CERAMIC,CHIP
2203-005792	C2038	C-CERAMIC,CHIP
2203-005806	C1040,C1055,C1076	C-CERAMIC,CHIP
2203-005806	C2010,C2032,C3033	C-CERAMIC,CHIP
2203-006121	C6039,C6042,C6043	C-CERAMIC,CHIP
2203-006123	L1006,L2006	C-CERAMIC,CHIP
2203-006187	C1105,C1110	C-CERAMIC,CHIP
2203-006194	C3007,C5014,C5145	C-CERAMIC,CHIP
2203-006305	C1036	C-CERAMIC,CHIP
2203-006379	C3012	C-CERAMIC,CHIP
2203-006400	C5068,C5076,C6033	C-CERAMIC,CHIP
2203-006423	C2000,C2001,C2005	C-CERAMIC,CHIP
2203-006423	C2006,C2008,C2009	C-CERAMIC,CHIP
2203-006423	C2039,C3014,C3049	C-CERAMIC,CHIP
2203-006423	C4004,C4007,C4009	C-CERAMIC,CHIP
2203-006423	C4015,C4017,C4018	C-CERAMIC,CHIP
2203-006423	C4021,C4022,C4024	C-CERAMIC,CHIP
2203-006423	C4025,C4029,C4030	C-CERAMIC,CHIP
2203-006423	C4031,C4034,C4042	C-CERAMIC,CHIP
2203-006556	C5031	C-CERAMIC,CHIP
2203-006604	C1039	C-CERAMIC,CHIP
2203-006611	L2014	C-CERAMIC,CHIP
2203-006665	C1079	C-CERAMIC,CHIP
2203-006674	C1058,L2013	C-CERAMIC,CHIP
2203-006839	C1001,C1003,C5140	C-CERAMIC,CHIP
2203-006839	C5143	C-CERAMIC,CHIP
2203-006841	C2068,C3045,C5086	C-CERAMIC,CHIP
2203-006841	C5093,C6003,C6028	C-CERAMIC,CHIP
2203-006846	C1013,C1014	C-CERAMIC,CHIP
2203-006872	C3047,C4033,C5040	C-CERAMIC,CHIP
2203-006872	C5050,C5051,C5135	C-CERAMIC,CHIP
2203-006872	C5136	C-CERAMIC,CHIP
2203-006968	C1006,C1009,C1052	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006968	C1068,L1028	C-CERAMIC,CHIP
2203-006979	C6000	C-CERAMIC,CHIP
2203-007194	C7007,L1070	C-CERAMIC,CHIP
2203-007271	C5020	C-CERAMIC,CHIP
2203-007279	C5021,C5066,C5067	C-CERAMIC,CHIP
2203-007279	C5075,C7002,C7005	C-CERAMIC,CHIP
2203-007317	C2050,C2058,C3010	C-CERAMIC,CHIP
2203-007391	C1056,C2042,C4005	C-CERAMIC,CHIP
2203-007391	C4008,C4010	C-CERAMIC,CHIP
2203-007392	C5072,C5080	C-CERAMIC,CHIP
2203-007425	C5054	C-CERAMIC,CHIP
2203-007781	C5095	C-CERAMIC,CHIP
2203-007796	C1035,C2069,C3008	C-CERAMIC,CHIP
2203-007796	C3048,C4000,C4001	C-CERAMIC,CHIP
2203-007796	C4002,C4003,C4006	C-CERAMIC,CHIP
2203-007796	C4011,C4012,C4013	C-CERAMIC,CHIP
2203-007796	C4014,C4016,C4023	C-CERAMIC,CHIP
2203-007796	C4028,C4032,C4039	C-CERAMIC,CHIP
2203-007796	C4040,C4041,C4046	C-CERAMIC,CHIP
2203-007796	C4047,C4049,C4050	C-CERAMIC,CHIP
2203-007796	C4051,C4052,C4053	C-CERAMIC,CHIP
2203-007796	C4056,C4057,C4058	C-CERAMIC,CHIP
2203-007796	C5004,C5007,C5010	C-CERAMIC,CHIP
2203-007796	C5011,C5012,C5013	C-CERAMIC,CHIP
2203-007796	C5032,C5033,C5035	C-CERAMIC,CHIP
2203-007796	C5036,C5038,C5043	C-CERAMIC,CHIP
2203-007796	C5045,C5046,C5047	C-CERAMIC,CHIP
2203-007796	C5052,C5057,C5058	C-CERAMIC,CHIP
2203-007796	C5059,C5060,C5061	C-CERAMIC,CHIP
2203-007796	C5062,C5071,C5073	C-CERAMIC,CHIP
2203-007796	C5074,C5078,C5081	C-CERAMIC,CHIP
2203-007796	C5084,C5094,C5102	C-CERAMIC,CHIP
2203-007796	C5103,C5105,C5106	C-CERAMIC,CHIP
2203-007796	C5115,C5116,C5117	C-CERAMIC,CHIP
2203-007796	C5118,C5126,C5127	C-CERAMIC,CHIP
2203-007796	C5128,C5129,C5137	C-CERAMIC,CHIP
2203-007796	C5138,C6027,C6036	C-CERAMIC,CHIP
2203-007796	C7006,C7011,C7012	C-CERAMIC,CHIP
2203-007796	C7017,C7018,C7019	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C7020,C7025,C7031	C-CERAMIC,CHIP
2203-007796	C7032,C7036,C7037	C-CERAMIC,CHIP
2203-007796	C7038,C7040,C7041	C-CERAMIC,CHIP
2203-007796	C7042,C7044,R6020	C-CERAMIC,CHIP
2203-008097	C6038	C-CERAMIC,CHIP
2203-008312	C4019,C4027,C4043	C-CERAMIC,CHIP
2203-008312	C5015,C5016,C5017	C-CERAMIC,CHIP
2203-008312	C5018,C5019,C5029	C-CERAMIC,CHIP
2203-008312	C5030,C5113	C-CERAMIC,CHIP
2203-008394	C3039,L1044	C-CERAMIC,CHIP
2203-008572	C5056	C-CERAMIC,CHIP
2203-008654	C6022	C-CERAMIC,CHIP
2203-008749	C6004,C6005	C-CERAMIC,CHIP
2203-008876	C1002,C1004,C1016	C-CERAMIC,CHIP
2203-008876	C1093,C1095,C2074	C-CERAMIC,CHIP
2203-008876	C5044,C5139,C6021	C-CERAMIC,CHIP
2203-008876	C6047	C-CERAMIC,CHIP
2203-008916	C5131	C-CERAMIC,CHIP
2203-009134	C1048	C-CERAMIC,CHIP
2203-009618	C6032,C6037	C-CERAMIC,CHIP
2203-009733	C5002,C5003,C5100	C-CERAMIC,CHIP
2203-009733	C7009,C7015,C7027	C-CERAMIC,CHIP
2203-009970	C1061,C5001,C5024	C-CERAMIC,CHIP
2203-009970	C5025,C5026,C6008	C-CERAMIC,CHIP
2203-009970	C6009,C6010,C6013	C-CERAMIC,CHIP
2203-009970	C6014,C6015	C-CERAMIC,CHIP
2203-010085	C5088,C5099	INDUCTOR-SMD
2703-002649	L2008	INDUCTOR-SMD
2703-002900	L1020,L1047,L2044	INDUCTOR-SMD
2703-002903	C2071,L1052,L1077	INDUCTOR-SMD
2703-002951	L2012	INDUCTOR-SMD
2703-002953	L1004,L1024	INDUCTOR-SMD
2703-002955	L6009,L6011	INDUCTOR-SMD
2703-002959	C3042,L2000,L2005	INDUCTOR-SMD
2703-002959	L3000	INDUCTOR-SMD
2703-003970	C3041,L1008,L1038	INDUCTOR-SMD
2703-004012	L1081,L1093,L2035	INDUCTOR-SMD
2703-004012	L3017	INDUCTOR-SMD
2703-004018	L2032,L3015	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004032	L1023,L1025,L1069	INDUCTOR-SMD
2703-004034	C1019,C1096,C1117	INDUCTOR-SMD
2703-004035	L1000,L1037,L1050	INDUCTOR-SMD
2703-004036	L1041	INDUCTOR-SMD
2703-004037	C1091,C1123,L1011	INDUCTOR-SMD
2703-004037	L1088,L1100,L2009	INDUCTOR-SMD
2703-004038	C2037,L1005,L1012	INDUCTOR-SMD
2703-004038	L1086,L2018,L3016	INDUCTOR-SMD
2703-004171	L1066	INDUCTOR-SMD
2703-004289	C3004,R3002	INDUCTOR-SMD
2703-004300	C1012,L1030,L1039	INDUCTOR-SMD
2703-004300	L1073,L1076	INDUCTOR-SMD
2703-004317	C1033,C1075,C2034	INDUCTOR-SMD
2703-004317	C2035,L1007,L1042	INDUCTOR-SMD
2703-004317	L1055,L1068,L1071	INDUCTOR-SMD
2703-004328	C1034,L1087	INDUCTOR-SMD
2703-004362	L1043,L1083,L1095	INDUCTOR-SMD
2703-004362	L2038,L2040	INDUCTOR-SMD
2703-004365	L1091	INDUCTOR-SMD
2703-004366	C1111,L1074,L2021	INDUCTOR-SMD
2703-004366	L2023,L2034	INDUCTOR-SMD
2703-004368	L1009,L1049,L1075	INDUCTOR-SMD
2703-004368	L2049	INDUCTOR-SMD
2703-004369	L2060,L3020	INDUCTOR-SMD
2703-004408	L3019	INDUCTOR-SMD
2703-004703	L3009	INDUCTOR-SMD
2703-004763	L2007	INDUCTOR-SMD
2703-004853	L1019,L1031,L1032	INDUCTOR-SMD
2703-004862	L1002,L1057,L1060	INDUCTOR-SMD
2703-004862	L1061	INDUCTOR-SMD
2703-004911	L1092	INDUCTOR-SMD
2703-005058	C1049,L1048,L1062	INDUCTOR-SMD
2703-005058	L2019	INDUCTOR-SMD
2703-005066	L6008	INDUCTOR-SMD
2703-005088	L2055	INDUCTOR-SMD
2703-005116	L6003	INDUCTOR-SMD
2703-005118	L6001	INDUCTOR-SMD
2703-005201	L5005,L5007	INDUCTOR-SMD
2703-005505	L5000,L5001,L5003	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-005505	L5004	INDUCTOR-SMD
2703-005581	L5013	INDUCTOR-SMD
2703-005718	L3018	INDUCTOR-SMD
2703-005833	L5012	INDUCTOR-SMD
2703-005838	L5002	CRYSTAL-UNIT
2801-005542	OSC5000	FILTER-EMI SMD
2901-001690	C4020,C4026,C4035	FILTER-EMI SMD
2901-001690	C4036,C4037,C4038	FILTER-EMI SMD
2901-001690	C4044,C4045	FILTER-SAW
2904-002143	F2000	FILTER-SAW
2904-002190	F2002	FILTER-SAW
2904-002198	F2001	FILTER-SAW
2904-002368	U2005	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2904-002417	F3001	FILTER-SAW
2904-002419	F2006	FILTER-SAW
2904-002435	F2004	FILTER-SAW
2904-002436	F1004	FILTER-DUPLEXER
2909-001382	F1001	FILTER
2910-000296	F1007	FILTER
2910-000301	F1011	FILTER
2910-000379	F1012	FILTER
2910-000385	F1006	FILTER
2910-000417	F1013	FILTER
2910-000420	F1009	FILTER
2911-000485	U2004	FILTER
2911-000495	U1000	MIC-CONDENSOR
3003-001256	MIC6000	CORE-FERRITE BEAD
3301-001895	L3013	CORE-FERRITE BEAD
3301-002085	L6002	CORE-FERRITE BEAD
3301-002122	L6013,L6014	CORE-FERRITE BEAD
3301-002235	C6035,L6007,L6010	CORE-FERRITE BEAD
3301-002235	L6012,L6015,L6016	CORE-FERRITE BEAD
3301-002236	L5008,L5009	CORE-FERRITE BEAD
3301-002237	L2017,L3010	CORE-FERRITE BEAD
3301-002238	L3012	CORE-FERRITE BEAD
3301-002242	L5010	CORE-FERRITE BEAD
3301-002243	L6004,L6005	CORE-FERRITE BEAD
3301-002244	L1001,L7000,L7001	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002244	L7002,L7003,L7004	CORE-FERRITE BEAD
3301-002254	L6000	CORE-FERRITE BEAD
3301-002331	L5006	CONNECTOR-COAXIAL
3705-001708	RFS1001	CONNECTOR-COAXIAL
3705-001937	RFS1000	CONNECTOR-CARD EDGE
3709-001932	SIM5001	CONNECTOR-CARD EDGE
3709-001933	SIM5002	CONNECTOR-CARD EDGE
3709-001934	SIM5000,SIM5003	CONNECTOR-SOCKET
3710-003871	SOC7002	CONNECTOR-SOCKET
3710-003874	SOC7003,SOC7004	CONNECTOR-SOCKET
3710-004008	CON5000	CONNECTOR-SOCKET
3710-004027	SOC7000,SOC7001	CONNECTOR-SOCKET
3710-004109	HDC3000	CONNECTOR-SOCKET
3710-004501	CN6000	CONNECTOR
3712-001604	ANT2001,ANT2002	CONNECTOR
3712-001604	ANT3000,ANT3003	CONNECTOR
3712-001604	ANT5000,ANT5001	CONNECTOR
3712-001634	ANT1001,ANT1002	CONNECTOR
3712-001666	ANT5002,ANT5003	CONNECTOR
3712-001666	ANT5004,ANT6000	CONNECTOR
3712-001666	ANT6001	-

5. MAIN Electrical Parts List

[SM-A125F]

Parts Code	Design LOC	Description
0202-002125	R5007,R5015,R5030	-
0202-002125	R6016,R6025,R7003	-
0202-002125	R7007,R7008,U7015	-
0202-002125	U7016	-
1001-001806	U4000	IC
1001-002065	U2006	IC
1108-000678	U5007	MEMORY
1205-006278	U3002	IC
2007-008516	R4003,R4007,R4008	R-CHIP
2007-008588	R2002,R3000,R3001	R-CHIP
2007-008588	R3005,R5009	R-CHIP
2007-009170	R4026	R-CHIP
2203-001153	C3032	C-CERAMIC,CHIP
2203-001239	C3028,C3031,C3035	C-CERAMIC,CHIP
2203-005736	C1041,C1047,C1077	C-CERAMIC,CHIP
2203-005736	C1094,C1097,C1113	C-CERAMIC,CHIP
2203-005736	C2002,C2003,C2004	C-CERAMIC,CHIP
2203-005736	C2011,C2012,C2013	C-CERAMIC,CHIP
2203-005736	C2015,C2017,C2018	C-CERAMIC,CHIP
2203-005736	C2070,C2079,C3000	C-CERAMIC,CHIP
2203-005736	C3001,C3002,C3011	C-CERAMIC,CHIP
2203-006400	C1015,C2041,C3022	C-CERAMIC,CHIP
2203-006400	C3027,C3036,C5064	C-CERAMIC,CHIP
2203-006423	C4054,C4055,C5000	C-CERAMIC,CHIP
2203-006423	C5039,C5053,C5079	C-CERAMIC,CHIP
2203-006423	C5082,C5085,C5087	C-CERAMIC,CHIP
2203-006423	C5089,C5092,C5142	C-CERAMIC,CHIP
2203-006423	C5147,C5149,C6044	C-CERAMIC,CHIP
2203-007317	C3019,C5009,C5048	C-CERAMIC,CHIP
2203-007317	C5049,C5055,C5096	C-CERAMIC,CHIP
2203-007317	C5107,C5112,C5132	C-CERAMIC,CHIP
2203-007317	C5133,C5146,C7001	C-CERAMIC,CHIP
2203-007317	C7003,C7004,C7010	C-CERAMIC,CHIP
2203-007317	C7021,C7022,C7023	C-CERAMIC,CHIP
2203-007317	C7024,C7050	C-CERAMIC,CHIP
2203-007393	C3018,C5022,C5023	C-CERAMIC,CHIP
2203-007393	C5041,C5101,C5141	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007393	C5144,C7014	C-CERAMIC,CHIP
2203-007796	C3013,C3017,C3023	C-CERAMIC,CHIP
2203-007796	C3024,C3026,C3046	C-CERAMIC,CHIP
2203-008860	C3021,C5027,C5083	C-CERAMIC,CHIP
2203-008860	C6023,C6048,C7016	C-CERAMIC,CHIP
2203-008860	C7035,C7039,C7043	C-CERAMIC,CHIP
2203-008860	C7045,C7046,C7047	C-CERAMIC,CHIP
2203-009167	C3029,C3034	C-CERAMIC,CHIP
2703-004013	C1054,C3003,L1078	INDUCTOR-SMD
2703-004013	L2022	INDUCTOR-SMD
2703-004014	L1003,L1013,L1056	INDUCTOR-SMD
2703-004014	L2003,L2031	INDUCTOR-SMD
2703-004030	L1079	INDUCTOR-SMD
2703-004032	L1082,L2045	INDUCTOR-SMD
2703-004033	C2043,C2044	INDUCTOR-SMD
2703-004034	L1063,L2016,L2025	INDUCTOR-SMD
2703-004034	L2048,L2053,L2054	INDUCTOR-SMD
2703-004034	L3002	INDUCTOR-SMD
2703-004035	L1080,L2004,L2037	INDUCTOR-SMD
2703-004035	L2039,L2046,L2056	INDUCTOR-SMD
2703-004317	L1084,L1090,L1094	INDUCTOR-SMD
2703-004367	L1010,L1040,L1102	INDUCTOR-SMD
2703-004367	L3004	INDUCTOR-SMD
2703-004764	L1035,L1046,L1059	INDUCTOR-SMD
2703-004764	L2026,L2041,L2050	INDUCTOR-SMD
2703-004764	L2051	INDUCTOR-SMD
2703-005555	L3011,L3014	INDUCTOR-SMD
2904-002252	F2005	FILTER-SAW
2910-000363	F1008	FILTER
3712-001634	ANT3001,ANT3002	CONNECTOR

5. MAIN Electrical Parts List

[SM-A125M]

Parts Code	Design LOC	Description
R5007,R5015,R5031	0202-002125	-
R6016,R6025,R7004	0202-002125	-
R7010,U7015,U7016	0202-002125	-
U2001,U2006,U2008	1001-002065	IC
U2010	1001-002065	IC
U1003	1001-002093	IC
U5007	1108-000698	MEMORY
R4004,R4007,R4008	2007-008516	R-CHIP
R2002,R5009	2007-008588	R-CHIP
C1041,C1077,C1082	2203-005736	C-CERAMIC,CHIP
C1094,C1097,C1101	2203-005736	C-CERAMIC,CHIP
C1113,C2002,C2003	2203-005736	C-CERAMIC,CHIP
C2004,C2011,C2012	2203-005736	C-CERAMIC,CHIP
C2013,C2015,C2017	2203-005736	C-CERAMIC,CHIP
C3000,C3001,C3011	2203-005736	C-CERAMIC,CHIP
C1015,C2041,C5064	2203-006400	C-CERAMIC,CHIP
C4054,C5000,C5039	2203-006423	C-CERAMIC,CHIP
C5053,C5079,C5082	2203-006423	C-CERAMIC,CHIP
C5085,C5087,C5089	2203-006423	C-CERAMIC,CHIP
C5092,C5142,C5147	2203-006423	C-CERAMIC,CHIP
C5149,C6044	2203-006423	C-CERAMIC,CHIP
C5009,C5048,C5049	2203-007317	C-CERAMIC,CHIP
C5055,C5096,C5107	2203-007317	C-CERAMIC,CHIP
C5112,C5132,C5133	2203-007317	C-CERAMIC,CHIP
C5146,C7001,C7003	2203-007317	C-CERAMIC,CHIP
C7004,C7010,C7021	2203-007317	C-CERAMIC,CHIP
C7022,C7023,C7024	2203-007317	C-CERAMIC,CHIP
C7050	2203-007317	C-CERAMIC,CHIP
C5022,C5023,C5041	2203-007393	C-CERAMIC,CHIP
C5101,C5141,C5144	2203-007393	C-CERAMIC,CHIP
C7014	2203-007393	C-CERAMIC,CHIP
C3013,C3017,C3046	2203-007796	C-CERAMIC,CHIP
C5027,C5083,C6023	2203-008860	C-CERAMIC,CHIP
C6048,C7016,C7035	2203-008860	C-CERAMIC,CHIP
C7039,C7043,C7045	2203-008860	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

C7046,C7047	2203-008860	C-CERAMIC,CHIP
C1031	2703-002901	INDUCTOR-SMD
C1054,C3003,L1022	2703-004013	INDUCTOR-SMD
L1078,L2022	2703-004013	INDUCTOR-SMD
L1003,L1013,L2003	2703-004014	INDUCTOR-SMD
L2031	2703-004014	INDUCTOR-SMD
L1082	2703-004032	INDUCTOR-SMD
C2043,C2044,L1026	2703-004033	INDUCTOR-SMD
L1027,L1064,L2016	2703-004034	INDUCTOR-SMD
L2025,L2048,L2053	2703-004034	INDUCTOR-SMD
L2054,L3002	2703-004034	INDUCTOR-SMD
L1080,L2004,L2029	2703-004035	INDUCTOR-SMD
L2037,L2039,L2056	2703-004035	INDUCTOR-SMD
L1084,L1085,L1090	2703-004317	INDUCTOR-SMD
L1094	2703-004317	INDUCTOR-SMD
L1010,L1040,L1045	2703-004367	INDUCTOR-SMD
L1102,L2030,L3004	2703-004367	INDUCTOR-SMD
L1035,L1046,L2026	2703-004764	INDUCTOR-SMD
L2041,L2050,L2051	2703-004764	INDUCTOR-SMD
F2003	2904-002304	FILTER-SAW
F1003	2910-000375	FILTER
F1000	2910-000416	FILTER

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.